

## Programming Your Remote.

Your remote control is already programmed to control your Digital Adapter. To use it to also control your TV set, follow the easy-to-use instructions in the User's Guide, provided with each remote.



# Your Digital Adapter is here.

# Turn it on.




### Box Contents



\*Digital Adapter



Remote Control



External 5V Power Supply Unit



Coaxial RF Cable (White Cable)



Remote Eye (IR Receiver)

AA Batteries (For your remote control)



Adhesive Fasteners

Note: We are not responsible for any damage that might be caused by using the adhesive fasteners.

To place your DA out of sight, use the supplied Remote Eye to receive signals from the remote control.


# ARMSTRONG®

ONE WIRE. INFINITE POSSIBILITIES.


\*Your Digital Adapter may differ slightly from the image shown.

# Connecting your new Digital Adapter.

1. Turn off your TV and disconnect the incoming cable from your TV. ....



2. Connect the cable to your new DA and set the switch on the back of the DA to Channel 3. ....




3. Connect the white cable to your new DA. ....



4. Connect the white cable to your TV. ....



5. Connect the power supply cord to your new DA and plug it into your wall outlet. ....



6. You're now ready to activate your DA!

- Turn on your TV and tune to channel 3.
- Messages will be displayed on the screen. Once you see them, you'll know you have correctly connected your DA.

**If you are installing multiple DAs, please connect ALL of them before proceeding with the next step.**

- Go online to [ArmstrongOneWire.com/Activate](http://ArmstrongOneWire.com/Activate) or call **1.855.511.0158** to activate your DA(s).